



## STRAIGHT DISTANCE



**Straight distance connector** helps install the basket strainer.

**parameters**

**Value**