



HEATING ZONE MANAGER AX 5100 ZN



Heating zone manager AX 5100 ZN allows for control the additional heating zone and the D.H.W. system. Intended to works with cascade manager AX 5200 SQ. Standard equipment:

- outside temperature sensor
- supply temperature sensor

parameters

Value

Operating temperature	0-40 °C
Dimensions	208x165x55 mm
Display	LCD
Contact load	230VAC/50/60Hz
Hysteresis	0,5-5 °C